

Walkways & Patios

Use of a 'landscape fabric' (geotextile) under a Walkway or Patio provides separation of the aggregate from the subsoil and reinforces the foundation soil reducing frost heaves and dislocation of the pavers, brick or stone.

For a Walkway/Patio fabric Under liner to perform effectively in soil stabilization and sub base applications, the product must be able to transfer its strength to the soil (below) and aggregate (above) while maintaining its reinforcing characteristics throughout the expected life of the project.

Note: The application of this product is most effective on sand or fine aggregate based systems.

Step #1

Remove soil including any rocks, sticks or stones. Remember to slope the walkway/Patio for removal of water.

Step #2

Install fabric, either side 'up' as illustrated below making sure that fabric is overlapped by at least 3" (inches) and secure by Pro-Pegs or Pro-Staples. This will help insure the separation of the soil and the rock dust or sand base.

Step #3

Install the Rock Dust and tamp down to remove all voids and air pockets. Be sure to check for desired slope. Install pea gravel or washed river stone and tamp down and check for a level grade.

Step #4 Install brick, pavers or bluestone walkway or patio and tamp down and check for a level grade.

Step #1



Step#2



Step#3



Step#4

